











CB...U



B...U



IB...U

143	IB	PAM		Motore normale / Standard motor / Normaler Motor / Moteur normal / Motor normal				Motore autofrenante / Brake motor / Bremsmotor Moteur frein / Motor-freno			
	~Kg	A	~Kg	X	Y	Z	~Kg	X	Y	Z	~Kg
100	132	76	124	326	191	139	138	407	191	139	143,5
112		76	124	347	211	154	148	443	211	154	158
132s		101	127	386	249	194	163	485	249	194	173
132m		101	127	434	249	194	172	537	249	194	187
160s		148	133	540	310	244	-	-	-	-	-
160l		148	133	584	310	244	-	-	-	-	-
180		148	133	641	349	260	-	-	-	-	-
200		185	148	-	-	-	-	-	-	-	-



Per le dimensioni relative alla zona attacco motore (Pm, Dm, bm, tm) fare riferimento alla tabella di pag. 190.

For the dimensions concerning the motor connection area (Pm, Dm, bm, tm) please refer to the table shown at page 190.

Zu den Abmessungen des Motoranschlußflansches (Pm, Dm, bm, tm) siehe Tabelle auf Seite 190.

Pour les dimensions concernant la zone de montage du moteur (Pm, Dm, bm, tm) lire SVP le tableau à la page 190.

Para las magnitudes correspondientes a la zona del motor (Pm, Dm, bm, tm) consulte la tabla de la página 190.



CB...U - FB

