












B...U



B...U



IB...U

153	IB	PAM		Motore normale / Standard motor / Normaler Motor / Moteur normal / Motor normal				Motore autofrenante / Brake motor / Bremsmotor Moteur frein / Motor-freno			
	~Kg	A	~Kg	X	Y	Z	~Kg	X	Y	Z	~Kg
132s	213	76	199	-	-	-	-	-	-	-	-
132m		76	199	-	-	-	-	-	-	-	-
160s		124	206,5	-	-	-	-	-	-	-	-
160l		124	206,5	-	-	-	-	-	-	-	-
180		124	206,5	-	-	-	-	-	-	-	-
200		161	221	-	-	-	-	-	-	-	-
225		161	223	-	-	-	-	-	-	-	-



Per le dimensioni relative alla zona attacco motore (Pm, Dm, bm, tm) fare riferimento alla tabella di pag. 190.

For the dimensions concerning the motor connection area (Pm, Dm, bm, tm) please refer to the table shown at page 190.



Zu den Abmessungen des Motoranschlußflansches (Pm, Dm, bm, tm) siehe Tabelle auf Seite 190.

Pour les dimensions concernant la zone de montage du moteur (Pm, Dm, bm, tm) lire SVP le tableau à la page 190.

Para las magnitudes correspondientes a la zona del motor (Pm, Dm, bm, tm) consulte la tabla de la página 190.



B...U - FB



B...U - FC

