




050	IS	PAM		Motore normale / Standard motor / Normaler Motor / Moteur normal / Motor normal				Motore autofrenante / Brake motor / Bremsmotor Moteur frein / Motor-freno			
	~Kg	A	~Kg	X	Y	Z	~Kg	X	Y	Z	~Kg
63	21	57	17.8	215	121	104	21.3	273	121	119	22.8
71		69	18.2	241	139	112	22.2	305	139	128	24.4
80		90	18.8	268	158	122	26.9	341	158	137	30.4
90s		90	18.8	296	173	130	30.8	373	173	130	36.3
90I		90	18.8	321	173	130	32.8	398	173	130	38.3
100		105	23	333	191	139	38.3	415	191	139	43.8
112		105	23	351	211	154	49.8	448	211	154	59.5




Per le dimensioni relative alla zona attacco motore (Pm, Dm, bm, tm) fare riferimento alla tabella di pag. 223.

For the dimensions concerning the motor connection area (Pm, Dm, bm, tm) please refer to the table shown at page 223.


Zu den Abmessungen des Motoranschlußflansches (Pm, Dm, bm, tm) siehe Tabelle auf Seite 223.

Pour les dimensions concernant la zone de montage du moteur (Pm, Dm, bm, tm) lire SVP le tableau à la page 223.


Para las magnitudes correspondientes a la zona del motor (Pm, Dm, bm, tm) consulte la tabla de la página 223.



S...C



IS...C



IS...FA - FB